

# INSTALLATION INSTRUCTIONS

## DP-RP-VM-07/08

**980175 rev.A**




980175 rev.A


[www.conteg.com](http://www.conteg.com)  
...to complete your network

# 1. Package includes:


## 1.1. for DP-RP-VM-08



## 1.2. for DP-RP-VM-07



## 1.3. Requested tools (not included)



Spanner size 6



Screwdriver cross

## 1.3. Legend



Working area





Hand manipulation





## 2. Assembly


### 2.1.






#### 2.1.1.




## 2.1.2.




## 2.1.3.




2.1.4.





2.1.5.







2.2.






2.2.1.



## 2.2.2.




## 2.2.3.







#### 2.2.4.



#### 2.2.5.





# CONTEG, spol. s r.o.

Headquarters:  
Na Vítězné pláni 1719/4  
140 00 Prague 4  
Czech Republic

Tel.: +420 565 300 300  
Fax: +420 565 533 955

conteg@conteg.com  
www.conteg.com

Production plant:  
K Silu 2179  
393 01 Pelhřimov  
Czech Republic

Tel.: +420 565 300 300  
Fax: +420 565 533 955

# Local Branches/Offices

Austria:	+43 170 659 0115
Benelux:	+32 477 957 126
Eastern Europe / Nordics:	+49 172 8484 346
France / Italy / Maghreb:	+33 686 074 386
Germany / Switzerland:	+420 724 723 184
India:	+91 991 6950 773
Middle East:	+971 4445 2838
Russia / CIS:	+7 495 967 3840
Saudi Arabia:	+966 594 30 13 08
Ukraine:	+380 674 478 240

